



## Cleaning Instructions for **aXtion<sup>®</sup> Slim**

We recommend cleaning the case after every use cycle. Most hospital-grade disinfectant wipes with high alcohol concentrate are safe to use on the **aXtion Slim** case. A few that we recommend are:

- Sani-Cloth AF3
- Cavi-Wipes
- Clorox Healthcare Bleach Germicidal Wipes

### **Follow these steps:**

1. Clean the back cover with a hospital-grade wipe, using a small stroking motion. Pay special attention to the crevices.
2. Use a new hospital-grade wipe to clean the front cover and screen protector.
3. Let the case air dry before using.

### **Internal cleaning may be done as needed following these steps**

1. Remove the tablet from the case and set aside.
2. Clean the inside back cover with a hospital-grade wipe, using a small stroking motion. Pay special attention to the crevices.
3. Use a new hospital-grade wipe to clean the inside front cover and screen protector.
4. Let the case air dry before putting the tablet into the case.

\* *Hospital-grade disinfectant wipes may have more detailed instructions for use. Please refer to the manufacturer's instructions.*

\* *These instructions are **only** for cleaning cases by The Joy Factory. To clean the tablet, please refer to the manufacturer's instructions.*

Contact us | [support@thejoyfactory.com](mailto:support@thejoyfactory.com)

**JOY**  
thejoyfactory